


Cleaning Alcoa® Wheels



Cleaning Dura-Bright® Wheels



- 

1. Allow wheels to cool below 35° C
Remove nut covers.
- 

2. Rinse with water.
- 

3. Mix water with a mild detergent or use undiluted Dura-Bright® Wheel Wash.
- 

4. Clean the wheel with a soft brush.
- 

5. Rinse with water.



Before

After

Watch the video instructions



youtu.be/QU9ggcm8HhI

Or look for “How to clean Dura-Bright® Alcoa Wheels”

Dura-Bright® Wheel Wash

- Helps to prevent the build-up of brake dust resin and copper glow
- No risk of damaging wheels with harsh chemicals
- No need to dilute
- Suitable for both XBR® and EVO technology



Arconic Wheel and Transportation Products

Industrieweg 135
B-3583 Paal, Belgium
www.alcoawheelseurope.com
www.alcoa-accessories.com

Tel: +32 11 45 84 60
Fax: +32 11 45 56 30
Email: info.wheels@arconic.com

Alcoa® Wheels is a product brand of Arconic
© 2018 Arconic Inc. or an Arconic Inc. affiliate



Cleaning Alcoa® Wheels




LvL ONE®, Polished and Brushed wheels



Rinse with warm water; preferably with a high pressure cleaner.



Pour a quantity of ALclean into a bucket and dilute with 1, 2 or 3 parts of water.




Recommended quantities:
 1. for difficult spots
 2. for medium pollution
 3. for regular use
 4. for frequent use



Gently brush ALclean onto the wheel.



Rinse with clean water.
Repeat these steps if needed.



Dry the wheel.


LvL ONE® and Polished wheels



Continue by applying a small amount of ALpolish.



Spread it evenly over the wheel using a moist cloth and polish the wheel.



Repeat steps 7 and 8 section by section to prevent the polish from drying out

Alcoa® Wheels cleaning products

ALclean

- Removes oxidation, disk brake dust, salt spray and general stains
- Suitable for Brushed, LvL ONE® and Mirror Polished finishes

ALpolish

- Restores shine of Mirror Polished and LvL ONE® finishes
- Use after ALclean

ALbrush2

- Rubber edge to avoid damage of the wheel
- 6 cm polyester plucked fibres



For additional information on cleaning and maintenance see page 84 of the Service Manual for Alcoa Wheels.